

INSTALLATION INSTRUCTIONS



FULL LENGTH

MIRRORS

All Bower mirrors include mounting hardware and are designed to be hung, not leaned. When your mirror arrives, one of the two brackets will already be attached to the back of the mirror. Install the second bracket on your wall by following the steps below.

If you have requested a spacer to accommodate for a baseboard, first install the spacer on the wall using the instructions described in Steps ① and ②. Then, repeat the process by screwing the bracket into the spacer so that their bottom edges align.

- ① Measure 62" (157.5cm) from the floor to the bottom of the mounting bracket.
- ② Use the screws provided to mount the bracket to drywall. Start with the center screw, then use a level to straighten the bracket before adding the remaining screws.
- ③ Lift the mirror up at least 2" (5 cm) off the floor to clear the bracket on the wall. With the mirror against the wall, slowly lower it until the brackets securely clip together and the mirror is hanging slightly above the floor.
- ④ Look into the mirror and pat yourself on the back :)

